

HQ6940, HQ6900



A

PHILIPS





www.philips.com

100% recycled paper
100% papier recyclé

4222.002.5061.2

1



ENGLISH

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome. The Super Lift & Cut system ensures a close and easy shave every day. For the best result, move the shaving heads over your skin in both straight and circular movements. Replace the shaving heads every two years for optimal shaving results.

General description (Fig. 1)

- A Protection cap
- B Shaving unit
- C Trimmer (HQ6940 only)
- D Trimmer slide (HQ6940 only)
- E Shaver on/off slide
- F Cleaning brush
- G Mains cord
- H Appliance plug

Important

Read this user manual carefully before you use the appliance and save it for future reference.

Danger

- Keep the shaver and the mains cord dry (Fig. 2).

Warning

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use the shaver or the mains cord if it is damaged.
- If the mains cord is damaged, always have it replaced with one of the original type in order to avoid a hazard.

Caution

- Always put the protection cap on the shaver to protect the shaving heads when you are travelling (Fig. 3).
- Only use the mains cord supplied.
- Store the appliance at a temperature between 5°C and 35°C.
- This appliance is not washable. Never immerse the appliance in water, nor rinse it under the tap.

Compliance with standards

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

General

The appliance is equipped with an automatic voltage selector and is suitable for mains voltages from 100 to 240 volts.

Using the appliance

Shaving

- Put the appliance plug in the shaver (Fig. 4).
- Put the mains plug in the wall socket.
- Push the on/off slide upwards to switch on the shaver.
- Move the shaving heads over your skin. Make both straight and circular movements (Fig. 5).
Shaving on a dry face gives the best results. Your skin may need 2 or 3 weeks to get accustomed to the Philips shaving system.
- Push the on/off slide downwards to switch off the shaver.
- Put the protection cap on the shaver every time you have used it, to prevent damage (Fig. 3).

Trimming (HQ6940 only)

You can use the trimmer to trim your sideburns and moustache.

- Push the slide upwards to open the trimmer (Fig. 6).

The trimmer can be activated while the motor is running.

Cleaning and maintenance

Regular cleaning guarantees better shaving performance.

This appliance is not washable. Never immerse the appliance in water, nor rinse it under the tap.

Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.

- For easy and optimal cleaning, Philips Shaving Head Cleaning Spray (type no. HQ110) is available. Ask your Philips dealer for information.

Note: Philips Shaving Head Cleaning Spray may not be available in all countries. Contact the Customer Care Centre in your country about the availability of this accessory. You can also clean the shaver in the following way:

Every week: shaving unit and hair chamber

- Switch off the shaver. Remove the mains plug from the wall socket and pull the appliance plug out of the shaver.
- Clean the top of the appliance first. Use the cleaning brush supplied (Fig. 7).
- Press the release button (1) and remove the shaving unit (2) (Fig. 8).
- Clean the inside of the shaving unit and the hair chamber with the cleaning brush (Fig. 9).
- Put the shaving unit back onto the shaver (Fig. 10).

Every two months: shaving heads

- Switch off the shaver. Remove the mains plug from the wall socket and pull the appliance plug out of the shaver.

- Press the release button (1) and remove the shaving unit (2) (Fig. 8).
- Turn the wheel anticlockwise (1) and remove the retaining frame (2) (Fig. 11).
- Remove the cutters and guards and clean them with the cleaning brush supplied (Fig. 12).

Note: Do not clean more than one cutter and guard at a time, since they are all matching sets. If you accidentally mix up the cutters and guards, it may take several weeks before optimal shaving performance is restored.

- Clean the cutter with the short-bristled side of the cleaning brush (Fig. 13).
Brush carefully in the direction of the arrow.

- Brush the guard (Fig. 14).

- Put the shaving heads back into the shaving unit. Put the retaining frame back into the shaving unit, push it down (1) and turn the wheel clockwise (2) (Fig. 15).

- Put the shaving unit back onto the shaver.

Extra thorough cleaning

For extra thorough cleaning, put the shaving heads in a degreasing liquid (e.g. alcohol) every six months. To remove the shaving heads, follow steps 1 to 4 described above. After cleaning, lubricate the central point on the inside of the guards with a drop of sewing machine oil to prevent wear of the shaving heads.

Trimmer (HQ6940 only)

Clean the trimmer every time you have used it.

- Switch off the shaver. Remove the mains plug from the wall socket and pull the appliance plug out of the shaver.
- Clean the trimmer with the cleaning brush supplied (Fig. 16).

Tip: Lubricate the trimmer teeth with a drop of sewing machine oil every six months (Fig. 17).

Storage

- Put the protection cap on the shaver to prevent damage (Fig. 3).

Replacement

Replace the shaving heads every two years for optimal shaving results. Replace damaged or worn shaving heads with HQ55 Philips Shaving Heads only.

- Switch off the shaver. Remove the mains plug from the wall socket and pull the appliance plug out of the shaver.
- Press the release button (1) and remove the shaving unit (2) (Fig. 18).
- Turn the wheel anticlockwise (1) and remove the retaining frame (2) (Fig. 11).
- Remove the shaving heads and place new ones in the shaving unit (Fig. 12).
- Put the retaining frame back into the shaving unit, push it down (1) and turn the wheel clockwise (2) (Fig. 15).
- Put the shaving unit back onto the shaver.

Accessories

The following accessories are available:

- HQ55 Philips Shaving Heads.
- HQ110 Philips Shaving Head Cleaning Spray (not available in China).

Environment

- Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 19).

Guarantee & service

If you need service or information or if you have a problem, please visit the Philips website at www.philips.com or contact the Philips Consumer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

Guarantee restrictions

The shaving heads (cutters and guards) are not covered by the terms of the international guarantee because they are subject to wear.

Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Centre in your country.

Problem	Cause	Solution
Reduced shaving performance.	The shaving heads are dirty. You have not cleaned the shaver well enough or you have not cleaned it for a long time.	Clean the shaver thoroughly before you continue shaving. See chapter 'Cleaning and maintenance'.
	Long hairs obstruct the shaving heads.	Clean the cutters and guards with the cleaning brush supplied. See chapter 'Cleaning and maintenance', section 'Every two months: shaving heads'.
	The shaving heads are damaged or worn.	Replace the shaving heads every 2 years for optimal shaving results. See chapter 'Replacement'.